


INSTALLATION INSTRUCTIONS

STELLARIS INTERNATIONAL

SURFACE MOUNT




FOR FULL WARRANTY INFORMATION AND COMPREHENSIVE INSTALLATION GUIDE, PLEASE VISIT WWW.LUCIFERLIGHTING.COM.

INSTALLATION INSTRUCTIONS

STELLARIS INTERNATIONAL STEM MOUNT



STEM ASSEMBLY




FOR FULL WARRANTY INFORMATION AND COMPREHENSIVE INSTALLATION GUIDE, PLEASE VISIT WWW.LUCIFERLIGHTING.COM.

INSTALLATION INSTRUCTIONS

STELLARIS INTERNATIONAL STEM MOUNT



STEM INSTALLATION



FOR FULL WARRANTY INFORMATION AND COMPREHENSIVE INSTALLATION GUIDE, PLEASE VISIT WWW.LUCIFERLIGHTING.COM.

STEM MOUNT



CMJB

3/4" EMT


Discard

1/2" EMT

Knock-out Removal


Knock-out

15 Lift fixture assembly, align keyholes slots of Twist-lock plate with screws of Mounting Plate, then twist to engage.




JUNCTION BOX MOUNTING PLATE (JBMP)

EXISTING 4/0 J-BOX



12 Install Mounting Plate


CEILING
MOUNT
JUNCTION BOX
(CMJB)



13 Attach Lanyards

Wiring
Diagrams on
last page

14 Make Wiring Connections



*Steps 15-18 apply to all mounting types (JBMP, CMJB, and ZERO-SIGHTLINE)

FOR FULL WARRANTY INFORMATION AND COMPREHENSIVE INSTALLATION GUIDE, PLEASE VISIT WWW.LUCIFERLIGHTING.COM.

LUCIFER
LIGHTING COMPANY

©2025 Lucifer Lighting Company


As part of its policy of continuous research and product development, the company reserves the right to change or withdraw specifications without prior notice.

[PH] +1-210-227-7329
[FAX] +1-210-227-4967


[DATE OF REV:09172025]
[LIT-DOM-INST-STELLARIS]

INSTALLATION INSTRUCTIONS

STELLARIS INTERNATIONAL CLEANING INSTRUCTIONS



- 1 After final cleaning of the space, remove protective film from waveguide. Avoid touching waveguide with hands.



- 2 Factory recommends cleaning waveguide assembly with a microfiber cloth or similar non-abrasive cloth. In most cases a damp microfiber cloth will remove dust/debris or fingerprints. For stubborn stains, approved cleaning agents include soap and water. Consult factory for other cleaning agents

FOR FULL WARRANTY INFORMATION AND COMPREHENSIVE INSTALLATION GUIDE, PLEASE VISIT WWW.LUCIFERLIGHTING.COM.

INSTALLATION INSTRUCTIONS

STELLARIS INTERNATIONAL


WIRING DIAGRAMS



WIRING NOTES:

IMPORTANT: The only connections required to be made are line voltage and control input as applied. Fixtures and LEDs are pre-wired to specification.

- Each LED source is provided with a separate driver.
- 0-10V drivers feature dim-to-off functionality. 0-10V drivers must be powered continuously, do not toggle power off.
- LED sources can be controlled independently or together. 0-10V drivers require separate control legs for independent control.



FOR FULL WARRANTY INFORMATION AND COMPREHENSIVE INSTALLATION GUIDE, PLEASE VISIT WWW.LUCIFERLIGHTING.COM.